Project: IEEE P802.15 Working Group for Wireless Personal Area Networks (WPANs)

Submission Title: Why/when is AWGN a suitable channel model for wireless front-/backhaul?

Date Submitted: 14 September 2015

Source: Sebastian Rey, Technische Universität Braunschweig Address: Schleinitzstr. 22, D-31806 Braunschweig, Germany

Voice: +49-531-391-2439, FAX: +49-531-391-5192, E-Mail: rey@ifn.ing.tu-bs.de

Abstract: This presentation gives reason that an Additive White Gaussian Noise Chanel is a suitable model for wireless front- and backhaul. In addition some clues on the necessary future coordination for such links is given..

Purpose: Input to provide a channel model for wireless front-/backhaul to TG3 d.

Notice: This document has been prepared to assist the IEEE P802.15. It is offered as a basis for discussion and is not binding on the contributing individual(s) or organization(s). The material in this document is subject to change in form and content after further study. The contributor(s) reserve(s) the right to add, amend or withdraw material contained herein.

Release: The contributor acknowledges and accepts that this contribution becomes the property of IEEE and may be made publicly available by P802.15.

Why/when is AWGN a suitable channel model for wireless front-/backhaul?


Sebastian Rey¹, Thomas Kürner¹

¹ Institut für Nachrichtentechnik, Technische Universität Braunschweig, Germany

Outline

- What has to be included in the channel model?
- 2. Simple Link Budget
- 3. Directive Antennas
 - Impact of Directive Antennas on the Channel
 - Real World Antennas
- 4. Conclusion

What has to be included in the channel?



- At first glance: every reflection/refraction/diffraction and scattering
- At second glance: everything less than 30 dB weaker than the direct path
- Typical distances
 Backhaul few 100m to several km (TRD, ARD); Fronthaul few 100m (TRD)
- Additional 30 dB of free space pathloss (FSL) correspond to a factor of ~31.5 in distance. For a direct path with a length of 100 m (1 km) a reflected path must at least have a length of 3.15 km (31.5 km) to be irrelevant

(Simple) Link budget for the direct path

SNR = 0 dBm transmitter power (baseband)

+ G_{tx} dBi antenna gain (transmitter)

- L_{FSL} dB free space loss

+ G_{rx} dBi antenna gain (receiver)

- 7.6 dB noise figure

- P_n dBm thermal noise

Required Antenna gain:

- 2x 26 dBi @ 100m
- 2x 36 dBi @ 1km

for $SNR = \sim 10 dB$


free space path loss at 300 GHz:

122 dB @100m 142 dB @1km

- required BER of 10^-12 after FEC (TRD, ARD)
- reasonable SNR = ~10 dB for a QPSK (see Doc. IEEE 802.15-15-13-0406-00-0thz)
- carrier frequency: 300 GHz bandwidth: 50 GHz

What kind of antenna?

- Suitable antennas are e.g.:
 - dish antennas
 - cassegrain antennas
 - may include lenses
- Common properties:
 - High antenna gain
 - No grating lobes, usually no side lobes
 - dimensions scale with gain and wave length




Assuming a Gaussian antenna pattern in elevation and azimuth:

HPBW	gain	gain-30 dB reached at (one antenna!)
1.5°	42.1 dBi	2.4°
2.5°	37.7 dBi	4.0°
5.0°	31.6 dBi	7.9°
10°	25.6 aBi	15.8°
15°	22.1 dBi	23.7°


A simple worst case evaluation

HPBW	gain	gain-30 dB	2x gain-30 dB
1.5°	42.1 dBi	2.4°	1.7°
2.5°	37.7 dBi	4.0°	2.8°
5.0°	31.6 dBi	7.9°	5.6°
10°	25.6 dBi	15.8°	11.2°
15°	22.1 dBi°	23.7°	16.8°



d=9.9 m @100 m distance for 10° HPBW d=24.5 m @1 km distance for 2.5° HPBW d=14.8 m @1 km distance for 1.5° HPBW


A slightly more sophisticated evaluation



And in the real world? (1)

- No dish antennas available at 300 GHz, yet
- Dish antennas for 71-86 GHz are available, e.g. Commscope VHLP200-80

Gain 41 dBi HPBW 1.5°



 Also Antennas with only 0.5° HPBW are available at 80 GHz


And in the real world? (2)


- At less than 15m -30dB is reached for one of these antennas at Tx and Rx:

Gain 41 dBi HPBW 1,5°

 With the Gaussian Antenna example 25m are required with a HPBW of 2.5° and also 15 m with ~1.5°

(SNR increased by 2x 5 dB)





- Multipath propagation is irrelevant (regarding the necessary planning process and the necessity to coordinate backhaul and fronthaul links with national regulators)
- AWGN sufficient for propagation aspects
- BUT still super wide band channels (more than ultra wide band)

Danke für Ihre Aufmerksamkeit! (Thank you for paying attention!)

Dipl.-Ing. Sebastian Rey rey@ifn.ing.tu-bs.de