IEEE 802.15 Wireless Personal Area Networks

	, , 11 01 0 2 2 1 0 12 0 11 0 0 1 (0 0 1) 0 1 12 0	
Project	IEEE 802.15 Working Group for Wireless Personal Area Networks	
Title	Response about CID #1141	
Date	May 18, 2010	
Submitted		
Source	Ying Li, Jaeseung Son, Sridhar Rajagopal, Taehan Bae, E.T. Won	
	[Samsung Electronics]	
	[yli2@sta.samsung.com]	
Re:		
Abstract	This document is the response about CID 1141.	
Purpose		
Notice	This document has been prepared to assist the IEEE 802.15. It is offered as a	
	basis for discussion and is not binding on the contributing individual(s) or	
	organization(s). The material in this document is subject to change in form and	
	content after further study. The contributor(s) reserve(s) the right to add, amend	
	or withdraw material contained herein.	
Release	The contributor acknowledges and accepts that this contribution becomes the	
	property of IEEE and may be made publicly available by 802.15.	

Change Requests

Text in blue and underscore: added <u>text</u>

Text in red and strikethrough: deleted text

On page 158, please make changes as follows).

7.3.11 Fast link recovery command

Fast link recovery command is used for the device or coordinator to send the fast link recovery (FLR) signal and the fast link recovery response (FLR RSP), to help the link recovery.

Fast link recovery signal and response use the same-fast link recovery command format. The fast link recovery command shall be formatted as illustrated in Figure xxx.

The FLR signal and FLR RSP are differentiated by the first bit (Bit 0) of the FLR field in the fast link recovery command frame. The device can indicate the index of FLR signal direction by using Bit 1-3 of the FLR field in the command frame. If the device receives the FLR signal and needs to send FLR RSP, it repeats the received FLR signal direction index by using Bit 1-3 of the FLR field in the command frame. If the device has only one direction, it uses '000' as the index of the direction.

octets: (see	1	1
7.2.2.6)		
MHR fields	Command Frame Identifier (see Table	FLR field
	73)	
		Bit 0: '0' indicating it is FLR signal
		'1' indicating it is FLR RSP
		Bit 1-3:
		Index of FLR signal direction, if Bit 0
		<u>is '0'.</u>
		Received FLR signal direction index if
		Bit 0 is '1'.
		Bit 4-7: Reserved

Figure xxx-Fast link recovery command