Project: IEEE P802.15 Working Group for Wireless Personal Area Networks (WPANs)

Submission Title: [Network Merging :

Design Strategies of An Ultra Low Power and High Reliability MAC] **Date Submitted:** [5 March, 2009] **Source:** [ShihHeng, Cheng and ChingYao, Huang] Company [National Chiao Tung University (NCTU), Taiwan] Address [1001 University Road, Hsinchu, Taiwan 300, ROC] Voice:[+886-919-572-936], FAX: [+886-3-572-2530], E-Mail:[fbil.ee91@gmail.com]

Re: [If this is a proposed revision, cite the original document.]

Abstract: [Network Merging , a WBAN-specific design strategy, is presented and analyzed. Without considering the unique features of WBAN, traditional wireless protocols fail the requirement and even induce negative impact. The unique features including the network mobility and imbalanced traffic loading are analyzed and corresponding design strategy, Network Merging, is suggested.]

Purpose: [Develop a Network Merging methodology for medical WBAN applications.]

Notice: This document has been prepared to assist the IEEE P802.15. It is offered as a basis for discussion and is not binding on the contributing individual(s) or organization(s). The material in this document is subject to change in form and content after further study. The contributor(s) reserve(s) the right to add, amend or withdraw material contained herein.

Release: The contributor acknowledges and accepts that this contribution becomes the property of IEEE and may be made publicly available by P802.15.

Network Merging

Design Strategies of An Ultra Low Power and High Reliability MAC

Outline

- U-PHI project, Taiwan
- Medical Wireless Body Area Network (WBAN)
- Requirements of medical WBAN
- Design strategy: Network Merging
- Evaluation of Network Merging
- Conclusion

Ubiquitous Personal Healthcare Inspector (U-PHI) project, Taiwan



Leaders:

•CMUH Medical Platform **Chair Ray-Jade Chen** •ECG Expert Sys **Prof. Chin-Teng Lin** •Front-end Ckt **Prof. Wei-Zen Chen** •Baseband Chip **Prof. Chen-Yi Lee** •MAC protocol **Prof. ChingYao Huang**

Medical Wireless Body Area Network



Graph: E. Jovanov, A. Milenkovic, C. Otto, "A wireless body area network of intelligent motion sensors for computer assisted physical rehabilitation" in *Journal of NeuroEngineering and Rehabilitation*, 2005.

Requirements of medical WBAN

- Ultra Low power
 - Tens of hours to years battery life time
 - Endoscopy >12 hours



http://www.olympus-europa.com/endoscopy/2001_5491.htm http://www.healthnode.org/tag/pacemaker/



Pacemaker >5 years

Requirements of medical WBAN

- Who needs ultra Low power?
 - End devices does.
 - Low power solutions of sensor network does not work due to its uniform power consumption!
- Energy efficiency of end device is more important than central device.
 - User rather recharges specific device than all devices.
 - Especially when number of devices > 24 (EEG, Neuron Apps)
 - Save End devices!



Requirements of medical WBAN

- High reliability (Qos of medical apps)
 - Definition? (#0644)
 - Latency < 20ms ? Jitter < 2ms ?
 - { Jitter < 2ms ?
 Reaction > 99.99% ?



✓ Real-time Display

✓Lossless data storage

– Sure thing :

Both real-time & data integrity should be considered for medical traffic.

Medical traffic loading > Traditional Real & non-Real traffics

- Need higher Channel efficiency
 - Avoid packet collision to increase capacity

March 2009

Design strategy: Network Merging

 Network Merging is a <u>collision free</u> protocol, which promises up to
 4x user number increase &
 29% battery life time improvement.

That is, 5 simultaneous users → 20 users 30 days battery life → 40 days



March 2009

Design strategy: Network Merging

• <u>Collision</u> is the major source of power consumption.

Power waste in traditional sensor network



Design strategy: Network Merging

- Simple Star Topology •
 - 3-5m radio range can cover most medical apps.
 - Upload-oriented traffic.



Power waste in traditional sensor network

Control message 💥 Assume traffic loading >> overhead Packet collision

- Overhearing Rx only! Not a problem of end device
- Idle listening [×] : End device is only a TX in most medical apps

Collision is the major source of energy waste in WBAN!

March 2009

• Network Merging synchronizes the Tx schedules of multi-WBAN.



Why not Beacon or CSMA/CA? *

(Beacon: cellular network, Bluetooth; CSMA: sensor, ad hoc, mesh networks)



* ShihHeng, Cheng, ChingYao, Huang, Power model for wireless body area network, BioCAS, Baltimore, MD, Nov, 20-22, 2008

(24 nodes x10 people)

- New collision source: inter-network collision.
 Reason: Moving network
 - WBAN moves with the position of user.
 - Traditional sensor network usually consider static or slowly move topology.
 - MANET considers "node" mobility.
 However, "network" mobility is more complex.



• Network Merging overcomes both intra & inter network collision.



Evaluation: Network Merging

• Synchronize Tx schedules of multiple WBANs



Evaluation: Network Merging

• Synchronize Tx schedules of multiple WBANs





Open issues

• Is there a better approach?

Overview of network merging

Advantage	Approach	Comparison with traditional solutions	Open issues
Optimize both power efficiency & channel capacity.	Solve the inter-WBAN collision by neighbor discovery and schedule negotiation.	 Beacon: very low power efficiency CSMA/CA: very low channel utility 	Tradeoff between direct and assisted inter-WBAN communication.

Conclusion

- Two major requirement:
 - low power & high reliability
- Two unique features:
 - Simple Star & Moving Network
- Network Merging
 - Solve intra & inter network collision
 Meet two WBAN requirements.